

Skirted Mobile Base Installation Instructions for Lista Cabinets

Instructions for installing the skirts to Lista cabinet(s) with skirted mobile base

Items & hardware included:

- 4 – #10-32 x 1/4" Phillips head screw (A109124)①
- 2 – End covers ②
- 2 – Front & Rear covers ③
- One Lista cabinet or two Lista cabinets bolted together side by side with a total of four casters

Tools required:

- Screwdriver or Cordless drill with a #2 Phillips driver

Before you begin:

- Before starting, make sure you have all four skirt covers & hardware listed above. Make sure the cover pieces are not bent or damaged.

End Covers:

- Start by attaching the end covers ②. There is no left or right, front or back as the parts are symmetrical. Insert the #10 x 1/4" Phillips head screws ① into each hole as shown in figure 1. Then align each screw with the holes in the flange at the bottom of the side or end of the cabinet.
- Tighten each screw using caution not to strip the hole (set cordless drill to a low torque setting). The assembled result should look like that shown in figure 2.
- Repeat the same procedure on the other end/side.

Front & Rear Covers:

- To assemble the front & rear covers ③ simply align the covers as shown in figure 2 (notch up).
- Then firmly push into place between the bottom of the cabinet & the flange of the end cover ②.
- Note that the dimples on the bottom flange of the front & rear covers ③ should engage or snap into the obround holes at the ends of each end cover ②.

Trouble Shooting

Problem: The front & rear covers ③ do not snap firmly into place or seem loose & rattle around.

Suggestion: Make sure the bottom flange on the end covers ②, as well as the bottom flange on the Front/Rear covers ③, are straight. If not use a rubber mallet or pliers to bend as needed. This will help to create a tighter fit.

